



Dear First-time User,

Both REDGUM Amplifolia *and* Black Series Signature Series amplifiers are controlled by our unique Dual Mono remote control.

Whenever power is first applied\* to the amplifier, nothing will happen for 2 seconds (while the Minimum Energy Performance Standard power supply stabilises). Then it will follow a **Power-On Self-Test** procedure – operating all controls and relays finally bringing the unit to StandBy mode. Only then is the unit ready for activation by the remote control handset.

N.B. For a step-by-step description of this process, please check REDGUM v7 Firmware, a single page following the Menu Options in the manual.

\* **BEFORE any power is applied**, please check that the **rocker switch on the rear panel** is in the **RESET position** (i.e. with NO red light visible).

