

Hookup of REDGUM Phono Preamp

Connect a high-quality Twin RCA lead from the 2 sockets on the front shown as output to any high level input of your amplifier. Connect the RCA leads from your turntable to the sockets shown as Input. Depending on the earthing system used in your turntable you may need to attach the thin (optional) earth wire to the Gnd terminal between the Input sockets.

A 9V DC power adapter (not supplied) is required to connect power to the preamp. Any basic electronic/electrical store should have such a unit in stock. The current required is less than 100ma. and the connector type is 2.1mm (.085 inch)

A press button switch on the front applies power to the electronics for operation.


No warmup time is required however the general belief is that audio improves with use, so feel free to leave the preamp running at all times - the total power drain is less than 5 watts.

Warranty Registration

Complete for v	Varranty Registration :
Name	
Address	
City	Zip code
Country	Date of purchase
Place of purchase	
Model No	
Serial No. (if any)	
	e REDGUM Audio factory at 3 9897 1399
	etails (incl. S.N.) to Predgumaudio.com>



redgumaudio.com warranty@redgumaudio.com



Operating Instructions
For
RGPH2 Phono Pre-amp



REDGUM Audio Pty Ltd Factory 3 - 25 Clarice Road Box Hill South 3128 Australia ABN 45 093 132 515